






How to connect SWAN from TV as BT Speaker

- Samsung TV

Press the front BT button from SWAN to change BT discoverable mode.

And, you can connect from TV' s setting menu as follows.





- LG TV

Press the front BT button from SWAN to change BT discoverable mode.

And, you can connect from TV' s setting menu as follows.

